



Service Schedule

Model	Focus RS	Repair/Order No	
Variant	2.5L DURATEC-15 TURBO (01/2009 -)	Reg. No.	
Interval	1 Years (12500 ml)	Reg. Date	
		Radio Code	
		Mileage	ml

Check for any outstanding service actions by using OASIS and ensure they are completed

Driving Vehicle into Workshop	
Instrument gauges, warning/control lights and horn	Check operation
Clutch	Check operation/adjust, if necessary
Washers, wipers	Check operation/adjust, if necessary
Inside Vehicle	
Exterior and respective control lights; instrument cluster illumination	Check operation/condition
Handbrake	Check operation/adjust, if necessary
Seat belts, buckles and stalks	Check operation/condition
Odour filter	Renew
Outside Vehicle	
Hood latch/safety catch & hinges	Check operation/grease
Under Hood	
Wiring, pipes, hoses, oil and fuel feed lines	Check for routing, damage, chafing and leaks
Engine, vacuum pump, heater and radiator	Check for damage and leaks
Coolant	Check anti-freeze concentration: ____°C
Coolant expansion tank and washer reservoirs	Check/top up fluid levels as necessary - in case of abnormal fluid loss, a separate order is required to investigate and rectify
Battery terminals	Clean, if necessary/grease
Battery	Visual check for leaks - in case of abnormal fluid loss, a separate order is required to investigate and rectify (LTS 31 214 4)
Under Vehicle	
Engine under-shield	Remove/install engine undershield, if fitted (LTS 21 130 4)
Engine	Drain oil and renew oil filter
Steering, suspension linkages, ball joints, sideshaft joints, gaiters	Check for damage, wear, security and rubber deterioration
Engine, transmission	Check for damage and leaks
Pipes, hoses, wiring, oil and fuel feed lines, exhaust	Check for routing, damage, chafing and leaks
Underbody	Check condition of PVC coating
Tyres	Check wear and condition, especially at tyre wall, note tread depth RF ____mm, LF ____mm, LR ____mm, RR ____mm
Brake system	With wheels off, check brake pads and discs for wear. Check rubber components for deterioration - in case of abnormal fluid loss, a separate order is required to investigate and rectify. (More often under severe duty conditions).
Outside Vehicle	
Engine	Refill engine oil - SAE 0W40 (WSS-M2C937-A)
Tyres	Adjust pressure
Instant mobility system	Check best before date on tyre sealant - replace if necessary
Spare wheel	Adjust pressure, check wear - condition (note tread depth) ____mm
Luggage compartment lamp	Check operation - if applicable
Wheel nuts	Tighten to correct torque and check for correct type. Check for rim damage
Wheel covers	Check for damages, especially at retainer system
Service reminder sticker	Affix to driver side B pillar

Extended Period Maintenance	
Brake system	Every 2 years - Renew - brake fluid (LTS 12 154 4)
Air conditioning	Every 3 years - Check temperature at the evaporator outlet tube. Check air conditioning lines for damage and leaks (LTS 34 619 1) (TSB 67/2002)
Cooling system	Every 10 years - Drain, flush and refill with Super Plus (LTS 24 122 4)
Camshaft drive belt, tensioner and idlers	Every 125 000 miles/10 years - Renew (LTS 21 304 9 and 21 306 5)
Auxiliary drive belts	Every 125 000 miles/10 years - Renew (LTS 21 567 5)
Extra Services and Additional Offers * (optional - upon customer request / charged seperately)	
AC maintenance package	Air Conditioning (A.C.) system check. Apply A.C. cleaner to air distribution system. (LTS 54 552 4)
Odour filter plus	Upgrade odour filter to odour filter plus